

Metal ion mediated electrooxidation of organic molecules: from *in situ* UV-Vis spectroelectrochemical perspective


Weiran Zheng, Lawrence Yoon Suk Lee*

Department of Applied Biology and Chemical Technology, The Hong Kong Polytechnic University, Hong Kong, China.


INTRODUCTION

- The electrooxidation process of small organic molecules, such as glucose and antibiotics, poses great importance in energy- and environment-related topics, yet hindered by high overpotential, involvement of noble metals, and strict requirement.
- To achieve high efficiency and low-cost of electrocatalyst, transition metal ions (for example, Cu(II)) are used in our work for both glucose and antibiotics electrooxidation, demonstrating high atomic efficiency and catalytic activity.
- Using *in situ* UV-Vis spectroelectrochemical methods, the mechanism of the metal ion mediated electrooxidation is proposed, indicating that the formed $\text{Cu}(\text{OH})_2^x$ species act as the active site *via* the formation of Cu(II)-organic molecule intermediate, which can be regenerated upon the formation and dissociation of Cu(III)-organic molecule complex.

EXPERIMENTAL SETUP




GLUCOSE ELECTROOXIDATION




The 273 and 360 nm peaks indicate CuO production as a result of CuOOH formation. After adding glucose, no CuO is produced at 650 mV.

In alkaline solution with only Cu(II):




with Cu(II) and glucose:





ChemElectroChem, 2017, 4, 2788-2792; Electrochimica Acta, 2019, 308, 9-19

ANTIBIOTIC ELECTROOXIDATION



linear sweep voltammetry


In alkaline solution with Cu(II) and antibiotics:



Cu(II)-antibiotic interaction is essential for antibiotic electrooxidation. For ampicillin, the concentration starts to decrease from 200 mV (vs. Ag/AgCl), a significantly lower potential than that of the other two antibiotics. The peak evolution reveals the kinetic aspects of antibiotics electrooxidation, showing multistep reaction mechanism.

In situ UV-Vis spectra

Reaction kinetics



(left) Long-term electrooxidation of antibiotics monitored by *in situ* UV-Vis spectroscopy provides kinetic information of antibiotics electrooxidation.

At 0.8 V (vs. Ag/AgCl), the electron transfer number is 1.23 (~1) for ampicillin electrooxidation, 4.78 (~5) for tetracycline, and 7.93 (~8) for chloramphenicol.

(right) Equilibrium between surface Cu(II) species and antibiotics molecules is instantly achieved in bulk solution. During electrooxidation, electrons are transferred from antibiotics either via a Cu(III)-antibiotic intermediate or a direct route to form Cu(II)-oxidized antibiotics.

Applied Catalysis B: Environmental, 2019, 256, 117824

CONCLUSION AND OUTLOOK

- Using metal ions in the electrolyte as the electrocatalysts for organic molecule electrooxidation shows excellent efficiency, which is comparable to metal-based nanostructure. Such route provides a more straightforward yet effective strategy toward electrocatalyst design.
- The complex intermediates formed due to coordination between active sites and substrate can be monitored by *in situ* UV-Vis spectroelectrochemistry, which benefits the mechanism discussion.